

Tex-Mex Popcorn Mix



Ingredients:

- 2 quarts air-popped popcorn
- 2 tsp. ground chili powder
- 2 tsp. paprika
- 2 tsp. ground cumin
- Butter-flavored cooking spray

Directions:

1. In a small bowl, combine all seasonings together.
2. Put popped popcorn in a large bowl and spray lightly with butter-flavored cooking spray.
3. Add spices to popcorn and mix thoroughly until all kernels are coated.